




# ESYSUNHOME 10KWH+H

User Guide & Installation Manual  
( V1-250103)



## ESYsunhome CO.,LTD

Website: [www.esysunhome.com](http://www.esysunhome.com)

Phone: +86 (0)755 8522 9087

Address: 301, building 6, No.5-2, inner ring road, Shanxia community, Pinghu street, Longgang District, Shenzhen, 518118 Guangdong P.R. China

Made in China

CE RoHS

ESYsunhome CO.,LTD

With over two decades of experience, ESY SUNHOME has swiftly gained prominence as a leading player in the energy storage industry, specializing in lithium battery technology and Battery Management Systems (BMS). Trusted by global giants such as Huawei, Dell, and Toshiba, ESY SUNHOME is renowned for its innovative solutions. Supported by advanced AI functionalities, protection systems and a highly skilled R&D team, the company's development of the HM series All-in-One residential energy storage systems marks a significant milestone in its pursuit of excellence.

With offices strategically located in Sydney, Australia, and Munich, Germany, ESY SUNHOME is well-positioned for global expansion, aiming to establish a significant international footprint. The company's unwavering commitment to making clean energy accessible drives its mission to empower communities worldwide in embracing sustainable solutions for a brighter future.

## Mission:

To provide safe and high-quality new energy products (batteries and power supplies) for every family.

## Vision:

Make clean energy available to every family.

## Core Values:

Unity and hard work;  
Pragmatic and far-reaching;  
Innovative research and development;  
Scientific and intelligent manufacturing;  
Creating value for customers;  
Creating opportunities;  
Contributing to society.

## Table of Contents

<b>1 Precautions</b>	<b>01</b>	<b>6 Battery power On and Off</b>	<b>34</b>
1.1 General statement	01	6.1 Power On	34
1.2 Safe Transportation and Storage	01	6.2 Power Off	35
1.3 Important Safety Information	02	6.3 Precautions	35
1.4 Installer Requirements	04	6.4 DC Connection Instructions	36
1.5 Installation safety precautions	04	6.5 Communication Between Battery	
1.6 Safety Symbols Description	05	and Inverter	36
<b>2 Product Introduction</b>	<b>06</b>	6.6 How to Set Up Battery Monitoring	37
2.1 Battery Parameters	06	6.7 BMS-STM8S-TI	38
2.2 Dimensions of battery system	10	6.7.1 BMS-STM8S-TI Software Connection	38
2.3 Schematic diagram of circuit		6.7.2 BMS-STM8S-TI Functional Operations	39
structure	11	6.8 Maintenance Instructions	49
2.4 Battery Port Descriptions	11		
2.5 Distribution Box Port Descriptions	13	<b>7 Distribution Box LED Display</b>	<b>33</b>
2.6 System Model Introduction	15	7.1 Status LED Display Descriptions	50
<b>3 Preparation Before Installation</b>	<b>16</b>	7.2 SOC LED Display Descriptions	51
3.1 Packing List	16	<b>8 After-sales Service</b>	<b>51</b>
3.1.1 Packing List of Battery	16		
3.1.2 Packing List of Distribution Box & Base	17		
3.1.3 Packing List of Cover	18		
3.1.4 Base Foot Packing List	18		
3.2 Selection of The Installation			
Environment	19		
3.3 Selection of Installation Location	20		
3.4 Preparation of Installation Tools	22		
<b>4 Installation</b>	<b>23</b>		
4.1 Floor-Mounted Installation	23		
4.1.1 Base Installation	23		
4.1.2 Batteries Installation	24		
4.1.3 Distribution Box Installation	25		
4.1.4 Inverter Installation	26		
4.1.5 Angle Iron Installation	26		
4.1.6 Battery Tower Installation	27		
4.2 Separate connection of battery			
and inverter	31		
<b>5 Wiring</b>	<b>32</b>		
5.1 Battery chassis ground	32		
5.2 Grounding Connection	33		
5.3 No AC Connection on the Batter	34		
5.4 Battery Isolation Device			
Description	34		

# 1 Precautions

## 1.1 General statement

- This manual mainly describes product information, installation, operation, and maintenance guidelines. The manual cannot include complete information about the system (i.e. inverter).

The device only includes batteries. Users can obtain additional information about other devices on [www.esysunhome.com](http://www.esysunhome.com) or contact local distributors to obtain the latest product information from the manufacturer.

- Please retain this manual properly, and strictly follow all safety instructions and operational instructions contained herein.
- ESY SUNHOME bears no responsibility for any consequences arising from failure to comply with the general safety requirements or safety standards for design, production, and use.
- It is crucial to use this product under specified design conditions. Any damage to components, personal injury, or property loss resulting from improper use will not be covered under warranty.
- During installation, use, and maintenance, adherence to all local laws and regulations is mandatory. The safety instructions provided in this manual are supplementary to local laws and regulations.
- The content in this manual will undergo periodic review and updates as needed. ESY SUNHOME reserves the right to make improvements or changes to the products and procedures described in this manual at any time without prior notice.
- The product diagram in this manual are used for illustrative purpose only. The product models depicted in the illustrations may differ from the actual product.
- The circuit diagrams in this manual are used for illustrative purpose only. Actual installation may be adjusted according to the local requirements and application scenarios.s
- Some products, accessories, functions, and services mentioned in this manual are optional items and may not be within your use scope.
- For further details, please consult authorized personnel or organizations of ESY SUNHOME.
- ESY SUNHOME reserves all rights to the final interpretation in this document.

## 1.2 Safe Transportation and Storage

- During transportation of the batteries, it is essential to utilize the original packaging to ensure the safety of the equipment throughout the shipping process.
- Upon receiving the shipments, please thoroughly inspect the external packaging of the batteries before opening the box for a comprehensive inspection.
- If any damage to the batteries occurs during transportation, please notify the shipping company immediately. The shipping company is responsible for any equipment damage incurred during transit. If necessary, seek assistance from the installation personnel or manufacturer.

- When handling inverters weighing 35 kg or more, please use appropriate equipment or collaborate with multiple individuals for safe handling.
- When storing the equipment, please use the original packaging and store it in a cool, dry, and well-ventilated area to prevent damage from moisture.

## 1.3 Important Safety Information

- Before installing, operating, and maintaining the equipment, please read this manual carefully.
- Make sure that the product is adequately grounded before operation. The grounding resistance should be less than  $0.1\Omega$ .
- Install all terminals of the energy storage system in accordance with the instructions provided in this manual. Follow the corresponding signs and symbols on the equipment during operation.
- During installation, please use the accessories provided in the product packaging.
- During maintenance, the maintenance personnel are prohibited from operating any equipment until all equipment has been shut down and completely discharged.
- The ports of the distribution box will be electrified during operation. Do not remove the protective covers of the parallel and communication ports of the distribution box when they are not in use.
- To ensure that the electrical parameters match requirements, relevant measuring equipment is required during system connection and testing. Ensure that the specifications of the equipment match to prevent arcing or impact.
- During instruction, maintenance and repair, warning signs shall be set up in the operational area of the system to prevent accidents caused by unauthorized personnel.
- Before installation, maintenance, or repair, use professional equipment to measure the voltage of the battery and distribution box terminals to prevent injury to operators from energized ports.

Danger!	
	<p>Risk of explosion</p> <ul style="list-style-type: none"><li>• Do not subject the battery to any strong force.</li><li>• Do not mechanically damage the battery (pierce, deform, strip down, etc.).</li><li>• Do not heat the battery or dispose of the battery in a fire.</li><li>• Do not install the battery in potentially explosive environments.</li></ul>
Danger!	
	<p>Risk of fire</p> <ul style="list-style-type: none"><li>• Do not expose the battery to temperatures in excess of <math>60^{\circ}\text{C}</math>.</li><li>• Do not place the battery near a heat source, such as direct sunlight, a fireplace, a thermally uninsulated wall exposed to sunlight, hot water, or a heater.</li><li>• Keep sources of ignition such as sparks, flames, and smoking materials away from the battery.</li></ul>

<b>Danger!</b>	
	<p>Risk of electric shock</p> <ul style="list-style-type: none"> <li>• Do not disassemble the battery.</li> <li>• Do not handle a wet battery or use wet tools.</li> <li>• Do not soak the battery in water or expose it to moisture or liquids.</li> <li>• Keep the battery away from children and animals.</li> <li>• Wear suitable clothing, guards and gloves to prevent you from direct contact with the DC voltage.</li> <li>• Use insulated tools during working with battery.</li> </ul>
<b>Danger!</b>	
	<p>Unauthorized removal, improper use, or incorrect installation or operation may result in serious personal injury or equipment damage. Therefore, transportation, installation, startup, dismantling, and maintenance must be carried out by qualified or trained personnel.</p>
<b>Danger!</b>	
	<p>Before undertaking any repair, electrical installation, or accessing any live parts, ensure that the inverter, distribution box, and battery are turned off, and that the port voltage is at a safe level.</p>
<b>Warning!</b>	
	<p>Installation must fully comply with national and local laws and regulations.</p>
<b>Warning!</b>	
	<p>Without permission, it is not allowed to replace the internal circuit of the battery distribution box.</p>
<b>Warning!</b>	
	<p>Before connecting to the grid, the product must be securely grounded. Please follow the instructions in this manual. Improper operation may cause serious damage.</p>
<b>Warning!</b>	
	<p>Please ensure that a lightning protection device is installed in the combiner box.</p>
<b>Warning!</b>	
	<p>After installation, repair, and maintenance, please lock the side door of the distribution box. Non professionals are not allowed to open the door.</p>

## 1.4 Installer Requirements

- The operators should be professionally qualified or trained.
- The operators should be familiar with the entire storage system, including its components and operating principles.
- The operators should be familiar with the product instruction.
- The grid-connected electricity selling of the energy storage system must be approved by the local power authority, or compliant with the relevant provisions of national and local laws and regulations. It must be conducted by qualified personnel.

## 1.5 Installation safety precautions

- The installation and use environment of lithium batteries must comply with relevant international, national, and local standards, as well as local laws and regulations.
- Ensure that the battery is not accessible to children and is kept away from areas of daily work or living, including but not limited to: offices, bedrooms, living rooms, music rooms, kitchens, studies, game rooms, home theaters, sunrooms, bathrooms, laundry rooms, and attics.
- When installing the battery in a garage, keep it away from the driveway.
- For basement installations, maintain good ventilation. Do not place flammable or explosive materials around the battery. It is recommended to install the battery on a wall to avoid contact with water.
- Install the battery in a dry and well-ventilated environment and secure it on a solid and flat surface.
- Install the battery in a concealed location or install a canopy above it to protect it from direct sunlight or rain.
- Install the battery in a clean environment without strong infrared radiation, organic solvents, and corrosive gases.
- For areas prone to natural disasters such as floods, earthquakes, and typhoons/hurricanes, appropriate installation precautions should be taken.
- Keep the battery away from ignition sources. Do not place any flammable or explosive materials around the battery.
- Keep the battery away from water sources such as faucets, drains, sprinklers, etc., to prevent water ingress.
- Do not install the battery in easily accessible locations, as the enclosure and heat sink temperature can be high when the battery is in operation.
- To prevent overheating, ensure that the vents and cooling system are not blocked when the battery is in operation.
- Do not expose the battery to flammable or explosive gases or smoke. Do not perform any operations on the battery in such environments.
- Do not install the battery on a moving object such as a boat, train, or car.

- Do not install the battery in outdoor areas affected by salt, as it may corrode. This area refers to a distance of up to 500 meters from the coast or areas susceptible to sea breeze influence. Areas susceptible to sea breeze influence may vary due to weather conditions such as typhoons and monsoons, or terrain features such as dams and hills.
- In the case of backup power, do not use the battery in the following situations:
  - Vital medical equipment for human life.
  - Control equipment for trains, elevators, etc.
  - Computer systems with social and public importance.
  - Locations near medical equipment.
  - Other devices similar to those described above.

## 1.6 Safety Symbols Description

The symbols that may be found in this product are defined as follows.

MODEL:ESYSUNHOME 10KWH+H battery	ESY SUNHOME: Brand Name 10KWH+H: Model, Indicates that the energy of the high-voltage battery is 10KWH+.
	Pay attention to safety.
	Attention: High surface temperature.
	No open flames Do not expose to flame, incinerate, puncture, or impact.
	Caution: Risk of electric shock.
	Prior to attempting any repair, electrical installation, or accessing any live parts, make sure that the inverter is switched off and wait for 5 minutes until internal capacitors are discharged to a safe voltage.
	Professional recycling and reuse are required.
	Please recycle this lithium ion battery. Do not discard.

	Please read this manual before using the product.
	Compliant with CE safety certification standards.
	TÜV mark of conformity
	This is a protective grounding terminal, which should be grounded securely to protect the safety of operators.
	This product is in compliance with RCM certification standards.

## 2 Product Introduction

### 2.1 Battery Parameters

MODEL	ESYSUNHOME 10KWH+H	ESYSUNHOME 10KWH+H-20	ESYSUNHOME 10KWH+H-30
Number of Batteries	1	2	3
Battery Capacity (kWh)	10.49	20.99	31.48
Usable Capacity (kWh)	10.28	20.57	30.85
Rate DC Power (kW)	3.30	6.60	9.90
Rated Capacity (Ah)	205	410	820
Size (LxWxH mm)	660x614x270	660x1020x270	660x1426x270
Installation width (mm)	660	660	660
Weight (kg)	119	214	309
Max.Continuous Charging Power (W)	3300	6600	9900
Max.Continuous Charging Current (A)	8.59	17.18	25.77
Max.Continuous Discharging Power (W)	3300	6600	9900
Max.Continuous Discharging Current (A)	8.64	17.28	25.92
Configuration	16S	(16S)2P	(16S)3P





MODEL	ESYSUNHOME 10KWH+H-40	ESYSUNHOME 10KWH+H-50	ESYSUNHOME 10KWH+H-60
Number of Batteries	4	5	6
Battery Capacity (kWh)	41.98	52.48	62.97
Usable Capacity (kWh)	41.14	51.43	61.71
Rate DC Power (kW)	13.20	16.50	19.80
Rated Capacity (Ah)	820	1025	1230
Size (LxWxH mm)	(660x1448x270)+ (660x614x270)	(660x1448x270)+ (660x1020x270)	(660x1448x270) x2
Installation width (mm)	1820	1820	1820
Weight (kg)	429.2	524.2	619.2
Max.Continuous Charging Power (W)	13200	16500	19800
Max.Continuous Charging Current (A)	34.36	42.95	51.54
Max.Continuous Discharging Power (W)	13200	16500	19800
MaxContinuous Discharging Current (A)	34.56	43.20	51.84
Configuration	(16S)4P	(16S)5P	(16S)6P

PARAMETERS	
Nominal Voltage	450 Vd.c
Max.Continuous Charging Power	3300 W
Max.Continuous Charging Current	7.33 A
Max.Continuous Discharging Power	3300 W
MaxContinuous Discharging Current	7.33 A
Battery Type	Li-ion
Voltage Range	380 V~560 V
Charging Voltage Declared by Manufacturer	480 V~560 V
Upper limit Charging Voltage	560 V
Discharging Cut off Voltage	380 V
Depth of Discharge	98%
Standard Temperature Range for Charging	-20 °C ~ 55 °C
Standad Temperature Range for Discharging	-10 °C ~ 50 °C
Storage temperature	-25 °C ~ 60 °C
Communication method	RS485/CAN
Charging conversion efficiency	96.1%
Discharging conversion efficiency	95.7%
Battery cycle life	Cycle 6000 times at a 0.2C rate in a 25 °C environment, which is 70% of the initial capacity
Dimensions (LxWxH)	(660 mm±2 mm)x(270 mm±2 mm)x(636 mm±2 mm)
Net weight	96.5 kg~97.5 kg
Install method	Floor mounting
Standards	IEC62619
EMC Standards	IEC61000-1 IEC 61000-3
Protection	over/under-voltage; overload; short circuit; over-temperature;
Ingress Protection Rating	IP66
Protection Class	I
Environmental certification	ROHS2.0
Transportation Safety Certification	UN38.3
Warranty	120 months
Country of Manufacture	China


MODEL	ESYSUNHOME 10KWH+H-70	ESYSUNHOME 10KWH+H-80	ESYSUNHOME 10KWH+H-90
Number of Batteries	7	8	9
Battery Capacity (kWh)	73.47	83.96	94.46
Usable Capacity (kWh)	72	82.28	92.57
Rate DC Power (kW)	19.80	19.80	19.80
Rated Capacity (Ah)	1435	1640	1845
Size (LxWxH mm)	(660x1448x270)x2 +(660x614x270)	(660x1448x270)x2 +(660x1020x270)	(660x1448x270) x3
Installation width (mm)	2980	2980	2980
Weight (kg)	739.4	834.4	929.4
Max.Continuous Charging Power (W)	19800	19800	19800
Max.Continuous Charging Current (A)	60.13	68.72	77.31
Max.Continuous Discharging Power (W)	19800	19800	19800
MaxContinuous Discharging Current (A)	60.48	69.12	77.76
Configuration	(16S)7P	(16S)8P	(16S)9P

Distribution box model	10KWH+H Distribution box
General parameter	
Supply voltage range	23 Vd.c~58 Vd.c
Rated operating range	450 Vd.c.
Operating voltage range	380 Vd.c.~550 Vd.c.
Ingress protection rating	IP66
Ambient temperature range	-20 ~ 55 °C
Port parameter	
Max. input power (Battery port)	9.9 kW
Max. input current (Battery port)	26 Ad.c.
Max. output power (Battery port)	9.9 kW
Max. output current (Battery port)	26 Ad.c.
Rated input/output power (Inverter port)	20 kW
Max. Input/input current (Inverter port)	50 Ad.c.
Max. input power (Parallel port)	15 kW
Max. input current (Parallel port)	39.5 Ad.c.
Max. output power (Parallel port)	19.8 kW
Max. output current (Parallel port)	52.1 Ad.c.


## 2.2 Dimensions of battery system



## 2.3 Schematic diagram of circuit structure




## 2.4 Battery Port Descriptions




### Purpose of each port on the battery

S/N	Name	Purpose
1	GP29Z(10KWH+H battery)	Connector
2	GP29T(10KWH+H Distribution box/10KWH+H battery)	Connector


### Schematic of the GP29Z Connector (10KWH+H Battery)



### Schematic of the GP29T Connector (10KWH+H Distributor Box/10KWH+H Battery)




## 2.5 Distribution Box Port Descriptions




Description of Distribution Box Wiring Ports

S/N	Description	Mark
1	Indicator light	SOC/ALM/RUN/CHG/DCHG
2	Power Button	/
3	Fuse Interface	FUSE+ / FUSE+ / FUSE- / FUSE-
4	Inverter Connection Port (GP29Z)	/
5	Battery Connection Port (GP29T)	/
6	Positive/Negative Terminal Interface for Battery Tower in Parallel (Left)	DC2+/DC2-
7	Battery Tower Communication Interface (Left)	PARALLEL2
8	Upper Computer Communication Interface	COM
9	Battery Tower Communication Interface (Right)	PARALLEL1
10	Battery Isolation Switch	BAT SWITCH (ON/OFF)
11	Positive/Negative Terminal Interface for Battery Tower in Parallel (Right)	DC2+ / DC2-

Schematic of the GP29Z Connector  
(10KWH+H Battery)



Schematic of the GP29T Connector  
(10KWH+H Distributor Box/10KWH+H Battery)



## 2.6 System Model Introduction



### Warning!



When using 10KWH+H batteries stacking system, please use the designated model of distribution box, inverter, and accessories.

Battery Capacity	Quantity of items required when installing batteries of different capacities :				
	Inverter	10KWH+H Battery	10KWH+H Distribution Box	10KWH+H Cover	10KWH+H Battery Base
10 kWh	1	1	1	0	1
20 kWh	1	2	1	0	1
30 kWh	1	3	1	0	1
40 kWh	1	4	2	1	2
50 kWh	1	5	2	1	2
60 kWh	1	6	2	1	2
70 kWh	1	7	3	2	3
80 kWh	1	8	3	2	3
90 kWh	1	9	3	2	3

Appearance of different system models:



## 3 Preparation Before Installation



### 3.1 Packing List

#### 3.1.1 Packing List of Battery


Item	Specifications	Quantity	Diagram
Battery	10KWH+H Battery	1	
Angle Iron	L79.5×65×25 mm	2	
Handlebar Screws	M4*35 mm	4	
Angle Iron Screws	M4*8 mm	2	
Waterproof Gasket	Silicone, black, matte, 104.5x50.3x10.6 mm	1	
Expansion Tubes	M6*40 mm, Used for Angle Iron	2	

Expansion Screw Gaskets	Inner diameter $\phi 5$ mm <sup>2</sup> ; Outer diameter $\phi 12$ mm <sup>2</sup> , SUS304 gasket	2	
-------------------------	--	---	---

### 3.1.2 Packing List of Distribution Box & Base

Items	Specifications	Quantity	Diagram
Distribution Box	10KWH+H Distribution Box	1	
LAN Port Connector	RJ45, assembly-type; Line diameter $\phi 3.0$ mm <sup>2</sup> ~ $\phi 6.0$ mm <sup>2</sup>	3	
Key	Triangular lock hole	2	
Handlebar Screws	M4*35 mm	4	
Waterproof Gasket	Silicone, black, matte, 104.5x50.3x10.6 mm	2	
Base	10KWH+H Battery Base	1	
Base Mounting Screws	M4*10 mm	4	


### 3.1.3 Packing List of Cover

Item	Specifications	Quantity	Diagram
Cover	10KWH+H Distribution Box Cover	1	
Positive Connection Cable for Battery Parallel	3 AWG, orange, length: 1600 mm	2	
Negative Connection Cable for Battery Parallel	3 AWG, black, length: 1600 mm	2	
Communication Matching Resistor	120 $\Omega$ between pin 5 and pin 8	2	


### 3.1.4 Base Foot Packing List

This accessory is used to adjust the height and balance of the base. It can be used when installing on the ground to accommodate uneven surfaces.


### 3.2 Selection of The Installation Environment




The ambient temperature should be  $-20^{\circ}\text{C}$  to  $55^{\circ}\text{C}$  and the relative humidity should be 0% to 95% (no condensation).




It can be installed outdoors, but must not be directly exposed to sunlight.




For stability, the product should be installed on solid and level ground.




Do not install it in damp or submerged areas.



Do not install it in areas prone to lightning strikes.




Do not install it near combustibles.




To ensure proper heat dissipation, please install it in a well-ventilated place.

### 3.3 Selection of Installation Location

Applicable scenario: When the batteries is used in an energy storage system.




The wall thickness should not be less than 50 mm.




The wall thickness should not be less than 50 mm.

The clearances around the batteries must not be less than the following:



Top	Front	Right (door side)	Left	Rear
800 mm	1000 mm	600 mm	300 mm	40 mm

### 3.4 Preparation of Installation Tools




## 4 Installation

### 4.1 Floor-Mounted Installation

#### 4.1.1 Base Installation


Tools and accessories required for this step:

Packing List of Battery	Battery
Packing List of Distribution Box	10KWH+H Battery Base, Waterproof Gasket (for Connector), Base Mounting Screws
Tools	Phillips Screwdriver PH1, Measuring Tape, Level




Step 1: Remove the dust cover from the connector port, flip the battery over with the bottom facing up.

Step 2: Align the waterproof port of the base with the battery (Do not remove the waterproof gasket for connector on the base).



Step 3: Use the base mounting screws to tighten the base, ensuring alignment between the battery and the base.

Step 4: Place the battery, with the base installed, on a suitable surface. Ensure that the back of the battery is 40 mm away from the wall.




#### Note

For uneven ground, please consider utilizing base foot accessories.


#### 4.1.2 Batteries Installation

Tools and accessories required for this step:

Packing List of Battery	Batteries, Waterproof Gasket (for Connector), Handlebar Screws
Tools	Open-end Wrench S=7 mm



Step 1: Place the waterproof gasket onto the connector on the top of the battery.



Step 2: Stack the batteries in sequence, tighten the handlebar screws on both sides of the batteries.



#### Warning!


Ensure that each battery tower contains NO more than 3 batteries.

#### 4.1.3 Distribution Box Installation




##### Warning!

Before completing the system installation, please check that the distribution box switch is in the "OFF" position.




Tools and accessories required for this step:

Packing List of Battery	Handlebar Screws, Waterproof Gasket (for Connector)
Packing List of Distribution Box	10KWH+H Distribution Box
Tools	Open-end Wrench S=7 mm



Step 1: Place the waterproof gasket onto the connector at the top of the battery.




Step 2: Stack the distribution box on the battery, tighten the handlebar screws on both sides of the battery.


#### 4.1.4 Inverter Installation

Tools and accessories required for this step:

Packing List of Distribution Box	Handlebar Screws, Waterproof Gasket (for Connector)
Packing List of Inverter	ESYSUNHOME HM10-H/ESYSUNHOME HM15/ESYSUNHOME HM20 Inverter
Tools	Open-end Wrench S=7 mm



Step 1: Place the waterproof gasket onto the connector at the top of the distribution box.




Step 2: Stack the inverter on the distribution box, tighten the handlebar screws on both sides of the distribution box.


#### 4.1.5 Angle Iron Installation

Tools and accessories required for this step:


Packing List of Battery	Angle Iron, Angle Iron Screws, Expansion Tubes with Screws, Expansion Screw Gaskets
Packing list of inverter	Angle Iron, Angle Iron Screws, Expansion Tubes with Screws, Expansion Screw Gaskets
Tools	Power Drill φM6, Hammer, Phillips Screwdriver PH1, Marker




Step 1: Place the angle iron screws through the angle irons and secure the angle irons to both sides of the topmost battery, but do not tighten the screws.




Step 2: Mark the position of the angle irons holes on the wall with a marker.



Step 3: Drill the holes at the marked positions with the power drill, and hammer the expansion tubes into the holes.



Step 4: Thread the expansion tube screws through the gaskets and angle iron holes, and secure them on the wall.






Step 5: Tighten the screws after adjusting the angle irons accordingly. The minimum torque value for M4 screws is 1.0 N·m. The minimum torque value for M6 screws is 3.5 N·m.




Step 6: Follow the same steps to install the inverter angle iron in the upper left corner of the inverter.

#### 4.1.6 Battery Tower Installation




Tools and accessories required for this step:

Packing List of Cover	10KWH+H Distribution box Cover, Positive Connection Cable for Battery Parallel, Negative Connection Cable for Battery Parallel
Packing List of Distribution Box	Handlebar Screws, Waterproof Gasket (for Connector)
Tools	Hammer, Measuring Tape




Step 1: Follow the battery installation steps, and install the battery towers.


Step 2: Install the waterproof gasket on the top connector of the distribution box.




Step 3: Securely place the cover on the distribution box, and tighten the handlebar screws on both sides of the distribution box.




Step 4: Remove the waterproof covers from the "parallel +" and "parallel -" ports of the distribution box.




Step 7: Install the communication cable for parallel connection of the distribution box as shown in the diagram.




Step 8: Connect the parallel communication cables to the communication port on the distribution box.




Step 5: Connect the positive terminals of adjacent distribution boxes in parallel using the positive connection cable from the distribution box of the battery tower.



Step 6: Connect the negative terminals of the adjacent distribution boxes using the negative cable from the distribution box in the battery tower.




Step 9: In the scenario with three battery towers, connect the parallel communication cables among the three distribution boxes as shown in the diagram.




Step 10: Inspect the wiring and install the communication matching resistors into the parallel communication interfaces on both sides of the distribution box.

	<b>Warning!</b>
Please retain the waterproof covers for the parallel ports of the distribution boxes.	
	<b>Warning!</b>
Please cover unused parallel ports with the waterproof covers.	


## 4.2 Separate connection of battery and inverter




The battery has two PACK+ ports and two PACK- ports. The top and bottom of the battery have dedicated GP29 connectors for direct connection.




To connect multiple batteries together, simply align them from bottom to top, ensuring the correct direction and position. There is no need for external connecting wires.



When connecting the inverter and battery, the inverter should be aligned and placed above the battery distribution box. Ensure that the direction and position are correct.




When connecting the distribution box to the battery, align and place the distribution box above the battery to ensure correct orientation and position.




When connecting the distribution box to the battery, align and place the distribution box above the battery to ensure correct orientation and position.

## 5 Wiring

### 5.1 Battery chassis ground



Attach the ring-shaped crimp cable lug to the right-side heat sink of the battery using the ground wire screw.




The ground wire only needs to be connected to the aluminum casing of the battery, which is safe and simple.


## 5.2 Grounding Connection

Tools and accessories required for this step:


Packing list of inverter	Ring-Shaped Crimp Cable Lug, Ground Screw
Tools	Crimping Pliers, Diagonal Pliers, Stripping Pliers, Phillips Screwdriver PH1, Measuring Tape
Cable	Ground Cable $\phi 6 \text{ mm}^2$




Step 1: Measure the distance between the ground wire connection aperture located on the side of the inverter and the combiner box using a measuring tape.



Step 2: Use stripping pliers to remove 4 mm of insulation from the grounding wire. Install the grounding wire terminal and crimp it tightly using crimping pliers.



Step 3: Attach the ring-shaped crimp cable lug to the right-side heat sink of the inverter using the ground wire screw.



Step 4: Properly ground the other end of the wire with a grounding impedance of  $0.1 \Omega$  or less to ensure safety in installation and operation.

## 5.3 No AC Connection on the Battery

The battery does not have an AC (alternating current) interface; it is equipped with a DC (direct current) interface.

There are two terminals labelled PACK+ and two labelled PACK-.

At the top and bottom of the battery, there are dedicated GP29 connectors for direct connection. Please refer to the battery port diagram for details.

The connection between the battery system and the inverter is in DC form. The AC interface of the inverter connects to the grid and backup power.

## 5.4 Battery Isolation Device Description

The battery's positive output terminal (P+) is controlled by the discharge control terminal (SW).

When there is no external connection, P+ does not output any power.

Power output is only enabled when an external connection is established, the control box or inverter is installed, and the battery switch is turned on.

Both battery terminals (P+ and P-) are isolated and covered with silicone caps. These caps must be removed during installation.

There is no voltage output during installation or removal.


The battery system must be installed together with the ESYSUNHOME inverters, which includes relays and an isolation switch.

# 6 Battery power On and Off


## 6.1 Power On

	<b>Warning!</b>
	Please double-check that the installation to ensure it is correct and reliable before powering on.
	<b>Warning!</b>
	Please shield unused ports with waterproof caps.
	<b>Warning!</b>
	After installation, please use the lock key to lock the door. Please take good care of the lock key.
	<b>Warning!</b>
	Please keep the unused connectors and accessories properly.

When powering on, please adhere to the following steps:




Step 1: Turn on the DC switch of the distribution box.




Step 2: Press and hold the power button on the distribution box for at least 5 seconds, and wait for the distribution box light to illuminate.


## 6.2 Power Off



Step 5: Turn off the DC Switch on the distribution box.



Step 6: Double-click the button on the distribution box to shut down the battery.



## 6.3 Precautions

If the inverter is not powered on for more than 7 days, please disconnect the circuit breakers for the battery, photovoltaic system, grid, and load.

When shutting down the system with multiple battery towers, double-click the buttons on all distribution boxes to deactivate the batteries, and switch off the DC switches on all distribution boxes as well.

After the system has been shut down for more than 7 days, when using it again, the inverter needs to be set to charging mode to charge all batteries to SOC=100%.

After the initial installation of the system, all batteries need to be charged to SOC=100%.

## 6.4 DC Connection Instructions


The battery has two PACK+ ports and two PACK- ports. Dedicated GP29 connectors are located at the top and bottom for direct battery connection.

When connecting the ESYSUNHOME inverters to the battery system, carefully align and place the inverter on top of the battery system. Ensure correct orientation and positioning.

	<b>Warning!</b>
	To prevent accidental discharge during transportation or installation, which may pose a safety risk to personnel or property, the battery pack is equipped with a discharge control terminal, located on the battery system connector.

	<b>Warning!</b>
	The battery can only discharge externally when it is connected via stacked installation to the ESYSUNHOME inverters, and the battery switch on the inverter is activated. Otherwise, the battery's external discharge function remains disabled.




## 6.5 Communication Between Battery and Inverter

After connecting the ESYSUNHOME inverters to the ESYSUNHOME battery system, please turn on the battery switch.

On the inverter side, it is permitted to connect to the grid, PV system, and household loads.

Once the power is on, the inverter will act as the master unit and initiate communication with the battery.

## 6.6 How to Set Up Battery Monitoring



Battery monitoring is configured through a dedicated **mobile app**.

When you want to view battery-related information, **connect your smartphone to the app**.

Through the app, you can access details such as:

- Number of connected battery modules
- Battery voltage
- Battery current
- Battery power
- Remaining battery capacity
- Battery operating status

## 6.7 BMS-STM8S-TI

BMS-STM8S-TI is a PC host software designed for ESYSUNHOME ESS Battery Models:

ESYSUNHOME 10KWH+H  
ESYSUNHOME 10KWH+H-20  
ESYSUNHOME 10KWH+H-30  
ESYSUNHOME 10KWH+H-40  
ESYSUNHOME 10KWH+H-50  
ESYSUNHOME 10KWH+H-60  
ESYSUNHOME 10KWH+H-70  
ESYSUNHOME 10KWH+H-80  
ESYSUNHOME 10KWH+H-90

### Battery Monitoring Features

The app includes the following functions:

- Viewing battery parameters
- Modifying battery settings
- Fault alarms
- Real-time battery status monitoring

### User Permissions


- Read-only: For users or inspectors. These settings can be viewed but not modified.
- Read and edit: For the battery manufacturer or authorized maintenance personnel. These settings can be edited by authorized personnel only.

### 6.7.1 BMS-STM8S-TI Software Connection

To connect the battery to the PC software, use the **GP29 cable** between the battery and the computer. Connect the USB adapter to the computer.

Use the **BMS-STM8S-TI software** provided with the battery for operation.


Communication is carried out via **RS485 protocol**.



## 6.7.2 BMS-STM8S-TI Functional Operations

### Communication Settings:

Configure the communication method, battery address, and the serial port used by the communication tool.



### Battery Monitoring:


View real-time data related to battery **voltage**, **current**, and **temperature**, as well as the software version and battery status.

ESYUNHOME tool PCS_3.3K High & low voltage_DCDC 8.0.0					
Start Stop Navigation Bar					
PCS_3.3K High & low voltage_DCDC					
- Settings					
- System Settings					
- Concise					
- Basic Analog Quantity					
- Basic Analog Quantity					
- Basic Setting Quantity					
- Basic Setting Quantity					
- Basic Control Command					
- Basic Control Command					
- Detailed					
- Setting Quantity					
- Control Command					
- Calibration					
- Analog Quantity					
- Analog Quantity					
- Test Analog Quantity					
- Balancing Test					
- Calibration					
- Calibrationb					
- Update					
- Download history					
Search: <input type="text"/>					
Run time: 00:00:22   1:COM3-1 9600,8,0,1   Communication State: <span style="color: green;">communicating</span>					

## 6.7.2 BMS-STM8S-TI Functional Operations

### Communication Settings:

Configure the communication method, battery address, and the serial port used by the communication tool.



### Battery Monitoring:

View real-time data related to battery **voltage**, **current**, and **temperature**, as well as the software version and battery status.

ESYUNHOME tool PCS_3.3K High & low voltage_DCDC 8.0.0					
Start Stop Navigation Bar					
PCS_3.3K High & low voltage_DCDC					
- Settings					
- System Settings					
- Concise					
- Basic Analog Quantity					
- Basic Analog Quantity					
- Basic Setting Quantity					
- Basic Setting Quantity					
- Basic Control Command					
- Basic Control Command					
- Detailed					
- Setting Quantity					
- Control Command					
- Calibration					
- Analog Quantity					
- Analog Quantity					
- Test Analog Quantity					
- Balancing Test					
- Calibration					
- Calibrationb					
- Update					
- Download history					
Search: <input type="text"/>					
Run time: 00:01:20   1:COM3-1 9600,8,0,1   Communication State: <span style="color: green;">communicating</span>					

## Basic Alarms:

Check whether the battery has any fault alarms and view the corresponding fault names. Alarms are categorized into **current alarms** and **historical alarms**.

Run time: 00:02:38 | 1:COM3-1[9600,8,0,1] | Communication State: Communication

## Basic Control Commands:

Control the **power on/off** of the battery output module, perform **initial value calibration**, and **clear faults**.

Run time: 00:06:21 | 1:COM3-1[9600,8,0,1] | Communication State: Communication

## Basic Settings:

Configure the basic parameters of the battery.

Run time: 00:05:11 | 1:COM3-1[9600,8,0,1] | Communication State: Communication

## Battery ID:

Read and edit the battery ID.

Run time: 00:06:41 | 1:COM3-1[9600,8,0,1] | Communication State: Communication

Run time: 00:05:29 | 1:COM3-1[9600,8,0,1] | Communication State: Communication

## Detailed Settings:

Configure detailed battery parameters, including alarm settings, protection parameters, heating functions, and cooling functions.

ESYSUNHOME Tool PCS\_3JK High & low voltage\_DCDC 8.0.0

Start Stop Navigation Bar Number of arguments in a single line [2]

PCS\_3JK High & low voltage\_DCDC

- Settings
  - System Settings
  - Commic Settings
- Scene
  - Concise
- Basic Analog Quantity
- Basic Alarm
- Basic Setting Quantity
- Basic Control Command
- Battery ID
- Detailed
  - Setting Quantity
  - Control Command
  - Calibration
  - Analog Quantity
  - Test Analog Quantity
  - Balancing Test
  - Calibration
  - Calibrationb
  - Update
  - Download history

Name	Echo	Unit	Range	Name	Echo	Unit	Range
1 Rectifier Module Feature Word 1	0			Rectifier Module Feature Word 2	0		
2 Software and Hardware Version Number 1	3			Software and Hardware Version Number 2	0		
3 Software Version	5015			Module Identification Code 0	2023		
4 Module Identification Code 1	101			Module Identification Code 2	0		
5 Module Identification Code 3	0			Reserved 9	0		
6 Default Output Voltage	360.0	V		DC Output Voltage Overvoltage Protection Point	700.0	V	
7 Default Current Limit Point	12.2	A		AC Current Limit Value Setting	10.0	A	
8 WAK-IN Time	0	s		Sequence Startup Interval Time	0	s	
9 Total Operating Time Low 16 Bits	0	h		Total Operating Time High 16 Bits	0	h	
10 Set Module Action After AC Phase Loss	0			Phase Loss Operation Enable Control	0		
11 Reserved 20	0			Reserved 21	0		
12 Reserved 22	0			Reserved 23	0		
13 Reserved 24	0			Reserved 25	0		
14 Reserved 26	0			Reserved 27	0		
15 Reserved 28	0			Reserved 29	0		
16 Bus Voltage Set Value Setting	450.0	V	380~1000	External Bus Low Voltage Alarm Point	45.8	V	
17 Primary Power Down (LLV)	43.2	V		Secondary Power Down (BLVD)	41.6	V	
18 Reserved 34	0			Reserved 35	0		
19 Reserved 36	0			Reserved 37	0		
20 Reserved 38	0			Reserved 39	0		
21 Reserved 68	0			Reserved 69	0		
22 Altitude	2000	m		Cold Mode	1		

Run time: 00:07:29 | 1:COM3-1[9600,8,0,1] | Communication State: Communication

ESYSUNHOME Tool PCS\_3JK High & low voltage\_DCDC 8.0.0

Start Stop Navigation Bar Number of arguments in a single line [2]

PCS\_3JK High & low voltage\_DCDC

- Settings
  - System Settings
  - Commic Settings
- Scene
  - Concise
- Basic Analog Quantity
- Basic Alarm
- Basic Setting Quantity
- Basic Control Command
- Battery ID
- Detailed
  - Setting Quantity
  - Control Command
  - Calibration
  - Analog Quantity
  - Test Analog Quantity
  - Balancing Test
  - Calibration
  - Calibrationb
  - Update
  - Download history

Name	Echo	Unit	Range	Name	Echo	Unit	Range
23 Charging Mode Heating Start Temperature	7	°C		Heating Off Temperature	19	°C	
24 Fan Start Temperature	50			Non-Charging Mode Heating Start Temperature	7	°C	
25 Reserved 76	0			Reserved 77	0		
26 Reserved 78	0			Reserved 79	0		
27 Reserved 80	0			Reserved 81	0		
28 Reserved 82	0			Reserved 83	0		
29 Reserved 84	0			Reserved 85	0		
30 Reserved 86	0			Reserved 87	0		
31 Reserved 88	0			Reserved 89	0		
32 Reserved 90	0			Reserved 91	0		
33 Flycapacitor Voltage Loop Proportional...	0.000			Flycapacitor Voltage Loop Integral Coefficient	0.0000		
34 Battery Average SOC Loop Proportional...	0.0250			Discharge Average SOC Control	0		
35 Charging Overvoltage Lock	3630	mV		Discharging Undervoltage Lock	2530	mV	
36 Charging Overcurrent Lock	100.0	A		Discharging Primary Overcurrent Lock	100.0	A	
37 Charging Overcurrent	Enabled			Discharge Enable	Enabled		
38 Battery Type	0			Battery Rated Capacity	206	Ah	
39 Single Cell Equalizing Charge Voltage	3.60	V		Single Cell Floating Charge Voltage	3.60	V	
40 Equalizing Charge to Floating Charge Cu...	0.01	C10		Maximum Equalizing Charge Time	24	h	
41 Floating Charge to Equalizing Charge Cu...	0.05	C10		Floating Charge to Equalizing Charge Cycle	9.0	day	
42 Charge Current Limit Coefficient	0.35	C10		Battery EOD Voltage	44.8	V	
43 Discharge Current Limit Coefficient	0.35	C10		Capacity Test Discharge Current Limit Coefficient	0.10	C10	
44 Lithium_Platinum_Prevention_Charging_Enable	Enabled			Operation Mode	1		

Run time: 00:07:56 | 1:COM3-1[9600,8,0,1] | Communication State: Communication

ESYSUNHOME Tool PCS\_3JK High & low voltage\_DCDC 8.0.0

Start Stop Navigation Bar Number of arguments in a single line [2]

PCS\_3JK High & low voltage\_DCDC

- Settings
  - System Settings
  - Commic Settings
- Scene
  - Concise
- Basic Analog Quantity
- Basic Alarm
- Basic Setting Quantity
- Basic Control Command
- Battery ID
- Detailed
  - Setting Quantity
  - Control Command
  - Calibration
  - Analog Quantity
  - Test Analog Quantity
  - Balancing Test
  - Calibration
  - Calibrationb
  - Update
  - Download history

Name	Echo	Unit	Range	Name	Echo	Unit	Range
44 Lithium_Plating_Prevention_Charging_Enable	Enabled			Operating Mode	1		
45 SOC Proportional Coefficient	8			Output Minimum Voltage	44.0	V	
46 Discharge Secondary Overcurrent Lock	190.0	A		Output Maximum Voltage	58.0	V	
47 Machine Model	1000			Default Value Version Number	1006		
48 Discharging Over Temperature Lock	58	°C		Charging Over Temperature Lock	58	°C	
49 Discharging Low Temperature Lock	-27	°C		Charging Low Temperature Lock	3	°C	
50 Number of Modules in Battery Cabinet	1			Number of Battery Cabinets	1		
51 Number of Modules in System	4			Number of Cells in Module	16	Num	1~16
52 Number of Temperature Sensors in Module	4			Single Cluster Rated Capacity	10	Ah	
53 Number of Modules per Cluster	1			Number of Cells Managed by Module per Cluster	15		
54 Number of Temperature Sensors Manage...	4			BMS Communication ID	1		
55 Rated Charging Voltage	57.6	V		Rated Charging Current	15.0	A	
56 Rated Discharging Current	100.0	A		Rated Discharging Voltage	40.0	V	
57 Battery Pack Overvoltage Alarm	3605	mV		Battery Pack Overvoltage Primary Protection	3610	mV	
58 Battery Pack Overvoltage Secondary Pr...	3620	mV		Battery Pack Overvoltage Protection Release	3400	mV	
59 Battery Pack Undervoltage Alarm	2780	mV		Battery Pack Undervoltage Primary Protection	2700	mV	
60 Battery Pack Undervoltage Secondary Pr...	2600	mV		Battery Pack Undervoltage Protection Release	2850	mV	
61 Charging Overcurrent Alarm	80.0	A		Charging Overcurrent Primary Protection	98.0	A	
62 Charging Overcurrent Secondary Protection	150.0	A		Charging Overcurrent Protection Release	70.0	A	
63 Discharging Overcurrent Alarm	90.0	A		Discharging Overcurrent Primary Protection	98.0	A	
64 Discharging Overcurrent Secondary Prote...	150.0	A		Discharging Overcurrent Protection Release	80.0	A	
65 Cell Balancing Enable Voltage	3300	mV		Cell Balancing Enable Voltage Difference	30	mV	
66 Cell Balancing Disable Voltage Difference	20	mV		Module Balancing Enable Voltage	0	mV	

Run time: 00:08:21 | 1:COM3-1[9600,8,0,1] | Communication State: Communication

ESYSUNHOME Tool PCS\_3JK High & low voltage\_DCDC 8.0.0

Start Stop Navigation Bar Number of arguments in a single line [2]

PCS\_3JK High & low voltage\_DCDC

- Settings
  - System Settings
  - Commic Settings
- Scene
  - Concise
- Basic Analog Quantity
- Basic Alarm
- Basic Setting Quantity
- Basic Control Command
- Battery ID
- Detailed
  - Setting Quantity
  - Control Command
  - Calibration
  - Analog Quantity
  - Test Analog Quantity
  - Balancing Test
  - Calibration
  - Calibrationb
  - Update
  - Download history

Name	Echo	Unit	Range	Name	Echo	Unit	Range
66 Module Balancing Enable Voltage Differe...	0	mV		Module Balancing Disable Voltage Difference	0	mV	
67 Single Cell Overvoltage Alarm	3405	mV		Single Cell Overvoltage Primary Protection	3610	mV	
68 Single Cell Overvoltage Secondary Prote...	3420	mV		Single Cell Overvoltage Protection Release	3400	mV	
69 Single Cell Undervoltage Alarm	2780	mV		Single Cell Undervoltage Primary Protection	2700	mV	
70 Single Cell Undervoltage Secondary Prot...	2600	mV		Single Cell Undervoltage Protection Release	2850	mV	
71 Charging Cell Imbalance Alarm	500	mV		Charging Cell Imbalance Primary Protection	1000	mV	
72 Charging Cell Imbalance Secondary Prot...	1500	mV		Charging Cell Imbalance Protection Release	300	mV	
73 Charging High Temperature Alarm	55	°C		Charging High Temperature Primary Protection	57	°C	
74 Charging High Temperature Secondary Pr...	58	°C		Charging High Temperature Protection Release	52	°C	
75 Discharging High Temperature Alarm	55	°C		Discharging High Temperature Primary Protection	57	°C	
76 Discharging High Temperature Secondary Pr...	58	°C		Discharging High Temperature Protection Release	52	°C	
77 Charging Low Temperature Alarm	6	°C		Charging Low Temperature Primary Protection	4	°C	
78 Charging Low Temperature Secondary Pr...	3	°C		Charging Low Temperature Protection Release	7	°C	
79 Discharging Low Temperature Alarm	-18	°C		Discharging Low Temperature Primary Protection	-20	°C	
80 Discharging Low Temperature Secondary Pr...	-25	°C		Discharging Low Temperature Protection Release	-16	°C	
81 Temperature Imbalance Alarm	20	°C		Temperature Imbalance Primary Protection	25	°C	
82 Temperature Imbalance Secondary Prote...	30	°C		Temperature Imbalance Protection Release	15	°C	
83 SOC Low Alarm	0	°C		SOC Low Primary Protection	0	°C	
84 SOC Low Protection Release	0	°C		SOC Low Secondary Protection	0	°C	
85 Insulation Resistance Low Primary Prote...	0	°C		Insulation Resistance Low Secondary Protection	0	°C	
86 Insulation Resistance Low Protection Rel...	0	°C		Insulation Resistance Low Protection Release	0	°C	
87 Fan Start Temperature	0	°C		Fan Start Current	0	A	

Run time: 00:08:42 | 1:COM3-1[9600,8,0,1] | Communication State: Communication

ESYSUNHOME Tool PCS\_3JK High & low voltage\_DCDC 8.0.0

Start Stop Navigation Bar Number of arguments in a single line [2]

PCS\_3JK High & low voltage\_DCDC

- Settings
  - System Settings
  - Commic Settings
- Scene
  - Concise
- Basic Analog Quantity
- Basic Setting Quantity
- Basic Control Command
- Battery ID
- Detailed
  - Setting Quantity
  - Control Command
  - Calibration
  - Analog Quantity
  - Test Analog Quantity
  - Balancing Test
  - Calibration
  - Calibrationb
  - Update
  - Download history

Name	Echo	Unit	Range	Name	Echo	Unit	Range
87 Fan Stop Temperature	0	°C		Fan Start Current	0	A	
88 Parallelizable Voltage Difference	0	V		Discharging Cell Imbalance Alarm	1000	mV	
89 Discharging Cell Imbalance Primary Prote...	1300	mV		Discharging Cell Imbalance Secondary Protection	1600	mV	
90 Discharging Cell Imbalance Protection Re...	800	mV		Battery ID0_1	12115		
91 Battery ID0_3	8270			Battery ID4_5	12337		
92 Battery ID6_7	22347			Battery ID6_9	11080		
93 Battery ID10_11	8264			Battery ID12_13	12338		
94 Battery ID14_15	13362			Battery ID16_17	14384		
95 Battery ID18_19	12592			Battery ID20_21	12336		
96 Battery ID22_23	12596			Battery ID24_25	0		
97 Battery ID26_27	0			Battery ID28_29	0		
98 Battery ID30_31	0			Battery ID32_33	0		
99 Battery ID34_35	0			Battery ID36_37	0		
100 Battery ID38_39	0			Battery ID40_41	0		
101 Battery ID42_43	0			Battery ID44_45	0		
102 Battery ID46_47	0			Battery ID48_49	0		
103 Battery ID50_51	0			Waveform Sampling Period	1		
104 Post-Trigger Data Portion	40			Condition Trigger Threshold	0		
105 Condition Trigger Type	1			Condition Trigger Source Selection	0		
106 Waveform Recording Channel 0 Data Sou...	0			Waveform Recording Channel 1 Data Source	22		
107 Waveform Recording Channel 2 Data Sou...	25			Waveform Recording Channel 3 Data Source	26		

Run time: 00:11:24 | 1:COM3-1[9600,8,0,1] | Communication State: Communication

ESYSUNHOME Tool PCS\_3JK High & low voltage\_DCDC 8.0.0

Start Stop Navigation Bar Number of arguments in a single line [2]

PCS\_3JK High & low voltage\_DCDC

- Settings
  - System Settings
  - Commic Settings
- Scene
  - Concise
- Basic Analog Quantity
- Basic Setting Quantity
- Basic Control Command
- Battery ID
- Detailed
  - Setting Quantity
  - Control Command
  - Calibration
  - Analog Quantity
  - Test Analog Quantity
  - Balancing Test
  - Calibration
  - Calibrationb
  - Update
  - Download history

Name	Echo	Unit	Range	Name	Echo	Unit	Range
1 DC Output Power Limit Set Value	0.0			DC Output Power Limit Value	0		
2 Force Sleep Enable				Balancing Control Enable	Forbidden		
3 Balancing Control	All Off			Module Power On/Off Control	0		
4 Fan Test Command	0			Battery Average SOC Command	0		
5 Module Address Allocation Control	0			Indicator Light Control	0		
6 Alarm Mask 1	0			Alarm Mask 2	0		
7 Alarm Mask 3	0			Balancing Chip Reset	Invalid		
8 Fault Clear Command	Invalid			Restore Defaults	0		
9 System Control Command 1	0			System Control Command 2	0		
10 Output Voltage Trim Value	0.0			Date and Time Calibration 1	0		
11 Date and Time Calibration 2	0			Date and Time Calibration 3	0		
12	--						
13 Balancing Control Enable	Forbidden			Balancing Control	All Off		
14	--			Cell1 Balancing Control	Off		
15 Cell2 Balancing Control	Off			Cell3 Balancing Control	Off		
16 Cell4 Balancing Control	Off			Cell5 Balancing Control	Off		
17 Cell6 Balancing Control	Off			Cell7 Balancing Control	Off		
18 Cell8 Balancing Control	Off			Cell9 Balancing Control	Off		
19 Cell10 Balancing Control	Off			Cell11 Balancing Control	Off		
20 Cell12 Balancing Control	Off			Cell13 Balancing Control	Off		
21 Cell14 Balancing Control	Off			Cell15 Balancing Control	Off		
22 Cell16 Balancing Control	Off			Waveform Recording Manual Trigger Enable	0		
23 Waveform Recording Condition Tri...	0			Parallel 485 Address	0		
24 Power Distribution Cabinet In-Plac...	0			Tooling Test Command	Ignore		
25 Battery Average SOC Value	0						

Run time: 00:11:24 | 1:COM3-1[9600,8,0,1] | Communication State: Communication

## Calibration:

Calibrate battery-related parameters such as voltage, current, and temperature.

Navigation Bar						
Number of arguments in a single line [2 -]						
PCS_3.3K High & low voltage_DCDC						
- Settings						
System Settings			1. Battery Input Voltage Calibration Coefficient a	1.028	0.9	Battery Input Voltage Calibration Coefficient b
Scene			2. Battery-Side Bus Voltage Calibration Coefficient a	1.030	0.9	Battery-Side Bus Voltage Calibration Coefficient b
- Concise			3. DC Input Voltage Calibration Coefficient a	1.001	0.9	DC Input Voltage Calibration Coefficient b
Basic Analog Quantity			4. DC-Side Bus Voltage Calibration Coefficient a	1.005	0.9	DC-Side Bus Voltage Calibration Coefficient b
Basic Alarm			5. LLC High-Voltage Side Voltage Calibration Coefficient a	1.000	0.9	LLC High-Voltage Side Voltage Calibration Coefficient b
Basic Setting Quantity			6. Flycapacitor Calibration Coefficient a	0.000	0.9	Flycapacitor Calibration Coefficient b
Basic Control Command			7. Battery Current Calibration Coefficient a	1.027	0.9	Battery Current Calibration Coefficient b
Battery ID			8. LLC Inductor Current Calibration Coefficient a	1.000	0.9	LLC Inductor Current Calibration Coefficient b
- Detailed			9. LLC High-Voltage Side Current Calibration Coefficient a	1.000	0.9	LLC High-Voltage Side Current Calibration Coefficient b
Basic Analog Quantity			10. Ambient Temperature Calibration Coefficient a	1.000	0.9	Ambient Temperature Calibration Coefficient b
Control Command			11. Radiator Temperature Calibration Coefficient a	1.000	0.9	Radiator Temperature Calibration Coefficient b
Calibration			12. LLC High-Voltage Side Radiator Temperature Calibration Coefficient a	1.000	0.9	LLC High-Voltage Side Radiator Temperature Calibration Coefficient b
Analog Quantity			13. LLC Low-Voltage Side Radiator Temperature Calibration Coefficient a	1.000	0.9	LLC Low-Voltage Side Radiator Temperature Calibration Coefficient b
Test Analog Quantity			14. DC Output Current Calibration Coefficient a	1.019	0.9	DC Output Current Calibration Coefficient b
Calibration			15. --	--	--	--
Calibrationb			16. --	--	--	--
Update			17. --	--	--	--
Download history			18. Battery Voltage Loop Proportional Coefficient	2.000		Battery Voltage Loop Integral Coefficient
			19. Battery Current Loop Proportional Coefficient	0.080		Battery Current Loop Integral Coefficient
			20. Bus Voltage Loop Proportional Coefficient	0.300		Bus Voltage Loop Integral Coefficient
			21. Inductor Current Loop Proportional Coefficient	0.010		Inductor Current Loop Integral Coefficient

## Analog Values:

View the battery's analog parameters, including voltage, current, temperature, state of charge, and charge/discharge status.

Navigation Bar						
Number of arguments in a single line [2 -]						
PCS_3.3K High & low voltage_DCDC						
- Settings						
System Settings			1. Battery Total Voltage	52.6	V	Charge/Discharge Status
Scene			2. BMS Self-Test Status	0		Standby
- Concise			3. BMS Operating Status 2	0		BMU Operating Status 1
Basic Analog Quantity			4. Battery Current	0.0	A	BMU SOC (State of Charge)
Basic Alarm			5. SOC (State of Health)	100.0	%	Maximum Temperature
Basic Setting Quantity			6. Module Number with Maximum Temperature	0		Internal Module Number with Maximum Temperature
Basic Control Command			7. Minimum Temperature	31.0	°C	Module Number with Minimum Temperature
Battery ID			8. Internal Module Number with Minimum Temperature	1		Highest Cell Voltage
- Detailed			9. Module Number with Highest Cell Voltage	0		3289 mV
Setting Quantity			10. Lowest Cell Voltage	3286	mV	Module Number with Lowest Cell Voltage
Control Command			11. Internal Module Number of Lowest Cell Voltage	3		Alarm Event
Calibration			12. Primary Protection Event	0		Detailed BMS Self-Test Status
Analog Quantity			13. Forced Charge/Discharge Status	Non-Forced		System Lock Event
Test Analog Quantity			14. BMU17-16 Voltage Status	0		BMU17-32 Voltage Status
Balancing Test			15. BMU17-16 Temperature Status	0		BMU17-32 Temperature Status
Calibration			16. Secondary Protection Event	0		Negative Half-Cell Current
Calibrationb			17. --	--	--	--
Update			18. --	--	--	--
Download history			19. --	--	--	--
			20. --	--	--	Module 1 Cell 1 Voltage
			21. Module 1 Cell 2 Voltage	3286	mV	Module 1 Cell 3 Voltage
			22. Module 1 Cell 4 Voltage	3286	mV	Module 1 Cell 5 Voltage

Run time: 00:15:09 | 1:COM3-1[9600,8.0,1] | Communication State: Connected

Navigation Bar						
Number of arguments in a single line [2 -]						
PCS_3.3K High & low voltage_DCDC						
- Settings						
System Settings			23. Module 1 Cell 6 Voltage	3287	mV	Module 1 Cell 7 Voltage
Scene			24. Module 1 Cell 8 Voltage	3287	mV	Module 1 Cell 9 Voltage
- Concise			25. Module 1 Cell 10 Voltage	3287	mV	Module 1 Cell 11 Voltage
Basic Analog Quantity			26. Module 1 Cell 12 Voltage	3286	mV	Module 1 Cell 13 Voltage
Basic Alarm			27. Module 1 Cell 14 Voltage	3288	mV	Module 1 Cell 15 Voltage
Basic Setting Quantity			28. Module 1 Cell 16 Voltage	0	mV	Module 1 Cell 17 Voltage
Basic Control Command			29. Module 1 Cell 18 Voltage	0	mV	Module 1 Cell 19 Voltage
Battery ID			30. Module 1 Cell 20 Voltage	0	mV	Module 1 Cell 21 Voltage
- Detailed			31. Module 1 Cell 22 Voltage	0	mV	Module 1 Cell 23 Voltage
Setting Quantity			32. Module 1 Cell 24 Voltage	0	mV	Module 1 Temperature 1
Control Command			33. Module 1 Temperature 2	31.0	°C	Module 1 Temperature 3
Calibration			34. Module 1 Temperature 4	31.0	°C	Module 1 Temperature 5
Analog Quantity			35. Module 1 Temperature 6	0.0	°C	Module 1 Temperature 7
Test Analog Quantity			36. Module 1 Temperature 8	0.0	°C	--
Balancing Test			37. --	--	--	--
Calibration			38. --	--	--	--
Calibrationb			39. --	--	--	--
Update			40. Input Power Low	0	W	Input Power High
Download history			41. Input Frequency	0.0	Hz	Input Current
			42. DC Output Power Low	0.0	W	DC Output Power High
			43. Real-Time Efficiency	1	%	DC Bus Voltage
			44. Output Actual Current Limit Point	343.5	A	Output Actual Power Limit Point

Run time: 00:15:39 | 1:COM3-1[9600,8.0,1] | Communication State: Connected

Navigation Bar						
PCS_3.3K High & low voltage_DCDC						
- Settings						
System Settings			45. LLC High-Voltage Side Voltage	0.3	V	Phase A Voltage
Scene			46. Phase B Voltage	0.0	V	Phase C Voltage
- Concise			47. Inlet Ambient Temperature	0.0	°C	Output Current
Basic Analog Quantity			48. Flycapacitor Voltage	0.0	V	Total Operating Time Low
Basic Alarm			49. Total Operating Time	0	h	Current Status 1
Basic Setting Quantity			50. Current Status 2	0		Battery SOC
Basic Control Command			51. Battery SOH (State of Health)	100	%	Battery Remaining Time
Battery ID			52. Input Total Power Low	0	W	Input Total Power High
- Detailed			53. Current Alarm/Status 1	0		Current Alarm/Status 2
Setting Quantity			54. Current Alarm/Status 3	0		Reserved 29
Control Command			55. Battery Input Voltage	52.6	V	Battery-Side Bus Voltage
Calibration			56. DC Input Voltage	0.1	V	DC Bus Voltage
Analog Quantity			57. LLC Inductor Current	0.00	A	LLC High-Voltage Side Current
Test Analog Quantity			58. Battery Current	-0.1	A	LLC High-Voltage Side Radiator Temperature
Calibration			59. LLC Low-Voltage Side Radiator Temperature	32.0	°C	Radiator Temperature
Calibrationb			60. Slot Address Bit 1	150		Slot Address Bit 2
Update			61. Slot Address Bit 3	0		R43_Maximum Interrupt Run Time
Download history			62. R44_1ms Task Average Time	200	us	R45_5ms Task Average Time
			63. R46_20ms Task Average Time	300	us	R47_100ms Task Average Time
			64. R48_ADBMS Voltage VD	0	mV	R49_ADBMS Voltage VA
			65. R50_ADBMS Voltage REF	100	mV	R51_Balancing Control
			66. R52_Balancing Control	0		R53_Program Guidance Flag

Run time: 00:16:01 | 1:COM3-1[9600,8.0,1] | Communication State: Connected

Navigation Bar						
PCS_3.3K High & low voltage_DCDC						
- Settings						
System Settings			1. R43_Maximum Interrupt Run Time	22.2	us	R44_1ms Task Average Time
Scene			2. R45_5ms Task Average Time	75	us	R46_20ms Task Average Time
- Concise			3. R47_100ms Task Average Time	525	us	--
Basic Analog Quantity			4. R48_ADBMS Voltage VD	0	mV	R49_ADBMS Voltage VA
Basic Alarm			5. R50_ADBMS Voltage REF	100	mV	R51_Balancing Control
Basic Setting Quantity			6. R52_Balancing Control	0		R53_Program Guidance Flag
Basic Control Command			7. R54_Program Guidance Flag	0		R55(unCellTemp_MiniCurC10)
Battery ID			8. R56(unCellInforbitb1ChargeDisable)	0		R57(unCellInforbitb1DischargeDisable)
- Detailed			9. R58(unCellVoltx_Q)	310		R59(unCellCurRx_Q)
Setting Quantity			10. --	--	--	Balancing Control Enable
Control Command			11. --	--	--	Forbidden
Calibration			12. Balancing Control	All Off		
Analog Quantity			13. Maximum Temperature	31.0	°C	Minimum Temperature
Test Analog Quantity			14. Lowest Single Cell Voltage	3286	mV	Highest Single Cell Voltage
Balancing Test			15. Module 1 Cell 1 Voltage	3286	mV	Cell1 Balancing Status
Calibration			16. Module 1 Cell 1 Voltage	Off		Module 1 Cell 2 Voltage
Calibrationb			17. Cell1 Balancing Control	Off		Cell1 Balancing Control
Update			18. Cell2 Balancing Status	Off		Cell2 Balancing Control
Download history			19. Module 1 Cell 3 Voltage	3286	mV	Cell2 Balancing Status
			20. Cell3 Balancing Control	Off		Module 1 Cell 4 Voltage
			21. Cell4 Balancing Status	Off		3286 mV
			22. Module 1 Cell 5 Voltage	3286	mV	Cell3 Balancing Control
			23. Cell5 Balancing Status	Off		Cell4 Balancing Status
			24. Cell6 Balancing Status	Off		Cell5 Balancing Status

Run time: 00:17:32 | 1:COM3-1[9600,8.0,1] | Communication State: Connected

ESYSUNHOME Tool PCS\_3JK High & low voltage\_DCDC 8.0.0

PCS_3JK High & low voltage_DCDC		Name	Echo	Unit	Name	Echo	Unit
Settings		23 Cell5 Balancing Control	Off		Module 1 Cell 4 Voltage	3287	mV
System Settings		24 Cell6 Balancing Status	Off		Cell6 Balancing Control	Off	
Commic Settings		25 Module 1 Cell 7 Voltage	3287	mV	Cell7 Balancing Status	Off	
Scene		26 Cell7 Balancing Control	Off		Module 1 Cell 8 Voltage	3287	mV
Concise		27 Cell8 Balancing Status	Off		Cell8 Balancing Control	Off	
Basic Analog Quantity		28 Module 1 Cell 9 Voltage	3287	mV	Cell9 Balancing Status	Off	
Basic Analog Quantity		29 Cell9 Balancing Control	Off		Module 1 Cell 10 Voltage	3287	mV
Battery ID		30 Cell10 Balancing Status	Off		Cell10 Balancing Control	Off	
Detailed		31 Module 1 Cell 11 Voltage	3287	mV	Cell11 Balancing Status	Off	
Setting Quantity		32 Cell11 Balancing Control	Off		Module 1 Cell 12 Voltage	3286	mV
Control Command		33 Cell12 Balancing Status	Off		Cell12 Balancing Control	Off	
Calibration		34 Module 1 Cell 13 Voltage	3289	mV	Cell13 Balancing Status	Off	
Analog Quantity		35 Cell13 Balancing Control	Off		Module 1 Cell 14 Voltage	3288	mV
Test Analog Quantity		36 Cell14 Balancing Status	Off		Cell14 Balancing Control	Off	
Balancing Test		37 Module 1 Cell 15 Voltage	3288	mV	Cell15 Balancing Status	Off	
Calibrationa		38 Cell15 Balancing Control	Off		Module 1 Cell 16 Voltage	3288	mV
Calibrationb		39 Cell16 Balancing Status	Off		Cell16 Balancing Control	Off	
Update		40	--		41	--	
Download history		42 b1FlashSOC1hadData	ok		b1DynamicBufferError	ok	
		43 b1FlashSOC3hadData	ok		b1FlashSOC2hadData	ok	
		44 b1DynamicBufferReadError	ok		b1FlashSOC4hadData	ok	
		45 b1DynamicBufferInitError	ok		b1DynamicBufferReadError	ok	
		46 b1BmsAppBufferError	ok		47	--	
		48	--		49	--	
		50	--		51	--	
		52	--		53	--	
		54	--		55	--	
		56	--		57	--	
		58 Cell 1 Temperature	0.0	°C	Cell 2 Temperature	0.0	°C
		59 Cell 3 Temperature	0.0	°C	Cell 4 Temperature	0.0	°C
		60 Cell 5 Temperature	0.0	°C	Cell 6 Temperature	0.0	°C
		61 Cell 7 Temperature	0.0	°C	Cell 8 Temperature	0.4	°C
		62 Cell 9 Temperature	0.0	°C	Cell 10 Temperature	0.0	°C
		63 Cell 11 Temperature	98.4	°C	Cell 12 Temperature	0.0	°C
		64 Cell 13 Temperature	0.0	°C	Cell 14 Temperature	0.0	°C
		65 Cell 15 Temperature	0.0	°C	Cell 16 Temperature	206.1	°C
		66 stSoxUnitData [1]Qmax	2061		stSoxUnitData [0]FCC	2028	
		67 stSoxUnitData [1]FCC	2028		68 stSoxUnitData [1]RemCap	1474	
		69 stSoxPublicData TotalChgAh	8875		70 stSoxPublicData TotalChgWh	47247	
		71	--		72 Sox_Calc_Qmax_From_SohCycle++	2	
		73 gr32PackCur_Battery Current	0.0	A	74 Maximum Temperature	31.0	°C
		75 Highest Single Cell Voltage	3288	mV	76	--	
		77	--		78 stSoxPublicData FlagFirstInit	0	
		79 stSoxPublicData FlagCurUpdate	0		80 stSoxPublicData FlagForceFull	0	
		81 stSoxPublicData FlagStableRelax	0		82 stSoxPublicData FlagStableDsg	0	
		83 stSoxPublicData FlagRestFuzCall	0		84 stSoxPublicData FlagChgFuzCall	0	
		85 stSoxPublicData FlagLowVoltModify	0		86 stSoxPublicData FlagSOC_9_LOCK	0	
		87	--		88	--	

ESYSUNHOME Tool PCS\_3JK High & low voltage\_DCDC 8.0.0

PCS_3JK High & low voltage_DCDC		Name	Echo	Unit	Name	Echo	Unit
Settings		45 b1BmsAppBufferError	ok		b1DynamicWriteToReadError	ok	
System Settings		46 b1BmsAppInitError	ok		b1BmsScErrorCntNum	ok	
Scene		47	--		48	--	
Concise		49	--		50	--	
Basic Analog Quantity		51	--		52	--	
Basic Analog Quantity		53	--		54	--	
Basic Analog Quantity		55	--		56	--	
Battery ID		57	--		58 Cell 1 Temperature	0.0	°C
Detailed		59 Cell 3 Temperature	0.0	°C	Cell 4 Temperature	0.0	°C
Setting Quantity		60 Cell 5 Temperature	0.0	°C	Cell 6 Temperature	0.0	°C
Control Command		61 Cell 7 Temperature	0.0	°C	Cell 8 Temperature	0.4	°C
Calibration		62 Cell 9 Temperature	0.0	°C	Cell 10 Temperature	0.0	°C
Analog Quantity		63 Cell 11 Temperature	98.4	°C	Cell 12 Temperature	0.0	°C
Test Analog Quantity		64 Cell 13 Temperature	0.0	°C	Cell 14 Temperature	0.0	°C
Balancing Test		65 Cell 15 Temperature	0.0	°C	Cell 16 Temperature	206.1	°C
Calibrationa		66 stSoxUnitData [1]Qmax	2061		stSoxUnitData [0]FCC	2028	
Calibrationb		67 stSoxUnitData [1]FCC	2028		68 stSoxUnitData [1]RemCap	1474	
Update		69 stSoxPublicData TotalChgAh	8875		70 stSoxPublicData TotalChgWh	47247	
Download history		71	--		72 Sox_Calc_Qmax_From_SohCycle++	2	
		73 gr32PackCur_Battery Current	0.0	A	74 Maximum Temperature	31.0	°C
		75 Highest Single Cell Voltage	3288	mV	76	--	
		77	--		78 stSoxPublicData FlagFirstInit	0	
		79 stSoxPublicData FlagCurUpdate	0		80 stSoxPublicData FlagForceFull	0	
		81 stSoxPublicData FlagStableRelax	0		82 stSoxPublicData FlagStableDsg	0	
		83 stSoxPublicData FlagRestFuzCall	0		84 stSoxPublicData FlagChgFuzCall	0	
		85 stSoxPublicData FlagLowVoltModify	0		86 stSoxPublicData FlagSOC_9_LOCK	0	
		87	--		88	--	

ESYSUNHOME Tool PCS\_3JK High & low voltage\_DCDC 8.0.0

PCS_3JK High & low voltage_DCDC		Name	Echo	Unit	Name	Echo	Unit
Settings		67 stSoxUnitData [1]FCC	2028		stSoxUnitData [0]RemCap	1450	
System Settings		68 stSoxUnitData [1]RemCap	1474		stSoxPublicData CycleCount	4	
Commic Settings		69 stSoxPublicData TotalChgAh	8875		stSoxPublicData TotalDsgAh	7606	
Scene		70 stSoxPublicData TotalChgWh	47247		stSoxPublicData TotalDsgWh	38989	
Concise		71	--		Sox_Cmax_SelfLearn++	0	
Basic Analog Quantity		72 Sox_Calc_Qmax_From_SohCycle++	2		gu16PackVol_Battery Voltage	52.6	V
Basic Setting Quantity		73 gr32PackCur_Battery Current	0.0	A	Standby		
Basic Control Command		74 Maximum Temperature	31.0	°C	Minimum Temperature	31.0	°C
Battery ID		75 Highest Single Cell Voltage	3288	mV	76	--	
Detailed		77	--		78 stSoxPublicData FlagFirstInit	0	
Setting Quantity		79 stSoxPublicData FlagCurUpdate	0		78 stSoxPublicData FlagInit_SOC	0	
Control Command		80 stSoxPublicData FlagForceFull	0		79 stSoxPublicData FlagInit_SOH	0	
Calibration		81 stSoxPublicData FlagStableRelax	0		79 stSoxPublicData FlagFullCharge	0	
Analog Quantity		82 stSoxPublicData FlagStableDsg	0		79 stSoxPublicData FlagUV	0	
Balancing Test		83 stSoxPublicData FlagRestFuzCall	0		79 stSoxPublicData FlagStableChg	0	
Calibrationa		84 stSoxPublicData FlagChgFuzCall	0		80 stSoxPublicData FlagRestEkf	0	
Calibrationb		85 stSoxPublicData FlagLowVoltModify	0		80 stSoxPublicData FlagOcvCall	0	
Update		86 stSoxPublicData FlagSOC_9_LOCK	0		80 stSoxPublicData FlagLowCurchg	0	
Download history		87	--		88	--	

## Balance Test:


View the status of the battery balancing function, whether it is enabled or disabled.

ESYSUNHOME Tool PCS\_3JK High & low voltage\_DCDC 8.0.0

PCS_3JK High & low voltage_DCDC		Number of arguments in a single line [3 -]		Number of arguments in a single line [3 -]	
PCS_3JK High & low voltage_DCDC		PCS_3JK High & low voltage_DCDC		Name	Echo
Settings		1	Balancing Control Enable	Forbidden	
System Settings		2	Maximum Temperature	31.0	°C
Commic Settings		3	Highest Single Cell Voltage	3286	mV
Scene		4	Module 1 Cell 1 Voltage	3286	mV
Concise		5	Module 1 Cell 2 Voltage	3286	mV
Basic Analog Quantity		6	Module 1 Cell 3 Voltage	3286	mV
Basic Setting Quantity		7	Module 1 Cell 4 Voltage	3286	mV
Basic Control Command		8	Module 1 Cell 5 Voltage	3287	mV
Battery ID		9	Module 1 Cell 6 Voltage	3287	mV
Detailed		10	Module 1 Cell 7 Voltage	3287	mV
Setting Quantity		11	Module 1 Cell 8 Voltage	3287	mV
Control Command		12	Module 1 Cell 9 Voltage	3287	mV
Calibration		13	Module 1 Cell 10 Voltage	3287	mV
Analog Quantity		14	Module 1 Cell 11 Voltage	3287	mV
Test Analog Quantity		15	Module 1 Cell 12 Voltage	3286	mV
Balancing Test		16	Module 1 Cell 13 Voltage	3288	mV
Calibrationa		17	Module 1 Cell 14 Voltage	3289	mV
Calibrationb		18	Module 1 Cell 15 Voltage	3288	mV
Update		19	Module 1 Cell 16 Voltage	3288	mV
Download history		20	Cell16 Balancing Status	Off	

## Download History Records:

Download the battery's operation logs, fault records, and status logs.



The battery should be kept clean, and the terminal and connectors should be cleaned regularly.

Different types and capacities of batteries should not be mixed. It is recommended to use batteries of the same model.

When installing or replacing the battery, remove any metal objects such as watches and rings from your hands to avoid the risk of short circuit and burns.

Battery maintenance should be performed or supervised by personnel with knowledge of batteries and with necessary precautions.

Batteries can present a risk of electric shock and high short-circuit current.

Do not throw batteries into fire. They may explode.

Do not open or damage batteries. The released electrolyte can be harmful to the skin and eyes, and may be toxic.

The battery module must not be opened. Any internal maintenance must be sent back to ESYUNHOME.

This product has an IP66 protection rating, and there are no maintainable parts, components, or cables on the exterior of the device.

It is recommended that maintenance be performed every six months to inspect connectors and grounding cables, and that this service be carried out only by our authorized after-sales service engineers.

## 6.8 Maintenance Instructions

### (Electrical Connection Maintenance and ESD Cleaning)

The surroundings of the battery enclosure should be kept clean, and any debris, dust, or accumulated water on the surface of the enclosure should be cleaned.

The floor of the battery installation area should be kept dry, and any accumulated water should be cleaned to prevent water damage.

The battery installation area should have proper ventilation, and any objects obstructing airflow should be moved.

High-temperature or heat-emitting objects should not be placed around the battery to avoid affecting its normal operation.

There is a ground wire inside the battery connecting to the enclosure, which is also connected to the inverter. Regularly check if the external grounding of the inverter is secure.

### Attention




The battery should be kept clean, and the terminal and connectors should be cleaned regularly. Different types and capacities of batteries should not be mixed. It is recommended to use batteries of the same model. When installing or replacing the battery, remove any metal objects such as watches and rings from your hands to avoid the risk of short circuit and burns.

### Warning



Battery maintenance should be performed or supervised by personnel with knowledge of batteries and with necessary precautions. Batteries can present a risk of electric shock and high short-circuit current. Do not throw batteries into fire. They may explode. Do not open or damage batteries. The released electrolyte can be harmful to the skin and eyes, and may be toxic.

## 7 Distribution Box LED Display



### Purpose of LED on the distribution Box

S/N	Mark	Purpose
1	SOC	SOC Indicator light
2	ALM	Alarm Status Indicator
3	RUN	Run (Operation) Status Indicator
4	CHG	Charging Status Indicator
5	DCHG	Discharging Status Indicator

## 7.1 Status LED Display Descriptions

### LED Display Descriptions

Status 1	Status 2	RUN	ALM	SOC Indicator Light	1 Bar	2 Bars	3 Bars	4 Bars
Power off	Sleeping	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Standby	Normal	Flash	OFF	The display is determined by the Average SOC indicator light status, which represents the average battery level for each battery tower.				
	Warning	Flash	Flash					
	Fault	OFF	Flash					
Charging	Normal	ON	OFF	The display is determined by the Average SOC indicator light status, which represents the average battery level for each battery tower.				
	Warning	ON	Flash					
	Fault	OFF	ON					
Discharging	Normal	ON	OFF	The display is determined by the Average SOC indicator light status, which represents the average battery level for each battery tower.				
	Warning	ON	Flash					
	Fault	OFF	ON					
Maintenance	Updating	Flash	Flash	Flash				

## 7.2 SOC LED Display Descriptions

Average SOC Status Descriptions								
Status	Charging				Discharging			
0%~25%	Flash	OFF	OFF	OFF	Flash	OFF	OFF	OFF
25%~50%	ON	Flash	OFF	OFF	ON	Flash	OFF	OFF
50%~75%	ON	ON	Flash	OFF	ON	ON	Flash	OFF
75%~100%	ON	ON	ON	Flash	ON	ON	ON	Flash
100%	ON	ON	ON	ON	ON	ON	ON	ON

## 8 After-sales Service

Service email: support@esysunhome.com

Or, Please contact the local installer.